DC Spec.	6.3 x 3.0mm
Type	15.0/19.0V
Notebook Brand	Nec, Toshiba, Acer

(15V)

Toshiba

Satellite 4015CDS
Satellite 2550
Satellite A25-S308 Series
Satellite A25-S307
Satellite A25-S2792
Satellite A25-S2791
Satellite A25-S279
Satellite A25-S208
Satellite A20-S259
Satellite A20-S208
Satellite A20-S207
Satellite Pro 470CDT
Satellite Pro 465CDX
Satellite Pro 465CDT
Satellite Pro 460CDX
Satellite Pro 460CDT
Satellite Pro 445CDT
Satellite Pro 440CT
Satellite Pro 440CS
Satellite Pro 440CDX
Satellite Pro 440CDT
Satellite Pro 430
Satellite 4100XDVD
Satellite 4090ZDVD
Satellite 4080CDT
Satellite 4070
Satellite 4060
Satellite 4030CDT
Satellite 4025CDT
Satellite 4020CDT
Satellite 4015CDT
Satellite 4010CDS
Satellite 4005CDT
Satellite 4005CDS
Satellite 4000CDT
Satellite 4000CDS
Satellite 330
Satellite 320
Satellite 310
Satellite 300
Satellite 2805
Satellite 2800
Satellite 2770
Satellite 2750
Satellite 2740
Satellite 2710
Satellite 2670
Satellite 2655XDVD
Satellite 2650
Satellite 2615DVD
Satellite 2610
Satellite 2590XDVD
Satellite 2590CDT
Satellite 2590CDS
Satellite 2530
Satellite 2520
Satellite 2510
Satellite 2505CDS
Satellite 2250
Satellite 2230
Satellite 2210XCDS
Satellite 2210CDT

Satellite 220
Satellite 2180CDT
Satellite 2140XCDS
Satellite 2100
Satellite 2060
Libretto U105

Satellite 200
Satellite 1555CDS
Satellite A20-S2591
Satellite A20
Libretto U100

A105-S4274
A105-S4284
A105-S4334
A105-S4342
A105-S4344
A105-S4364
A105-S4384
A105-S4001
A105-S4002
A105-S4004
A105-S4011
A105-S4012
A105-S4014
A105-S4021
A100-S8111TD
A100-SP471
A100-ST1042
A100-ST8211
A105-S4022
A105-S4024
A105-S4034
A105-S4051
A105-S4054
A105-S4064
A105-S4074
A105-S4084
A105-S4092
A105-S4094
A105-S4102
A105-S4104

A105-S4114
A105-S4124
A105-S4132
A105-S4134
A105-S4201
A105-S4204
A105-S4211
A105-S4214
A105-S4244
A105-S4254
A1
A2
A3
A4
M1
M2
M3
M4
M2
S1
S2
M30
M35
M40
M45
R10
R15
2010
3500
3505

4000
4005
4010
TE2300
9100
TE2000
E2100

(19V)

TOSHIBA

Satellite 1400, 1405, 1410, 1415, 1800 (except -S203 & -S253), 1805 (except -S203, -S253 & -S273), 2400, 2405, 2410, 2415, 5005, 5105, 5200, 5205, A10,A15, A50, A55, M20, M30, M35,
M40 (except M40-S312TD), M45 (except M45-S165, M45-S169, M45-S165X & M45-S169X), M50, M55 (except M55-S139, M55-S141, M55-S1001 & M55-S1391 & M55-S1412), R10, R15, R20, R25, U200,
U205; Satellite Pro 6000, 6100, M10, M15, S300, S300M; Portege 3500, 3505, 4000, 4005, 4010, M100, M200, M205, M400, M405, M700, M750, M780, R200, and S100 series; Tecra 9000, 9100, A1, A2,
A3, A4, A5, A8, A9, A10, A11, M1, M2, M2V, M3, M4, M5, M6, M7, M9, M10, M11, R10, S1, S2, S3, TE2000, TE2100, TE2300 series portable computers

---

DC Spec.	5.5 x 2.5mm	
Type	16.0/18.5/19.0/20.0V	
Notebook Brand	Asus, Acer IBM, Dell, HP, Compaq, Fujitsu, Toshiba, NEC, Liteon, Lenovo	

(16V)

IBM

ThinkPad 235
ThinkPad 240
ThinkPad 240X
ThinkPad 240X
ThinkPad 240Z
ThinkPad 290
ThinkPad 310
ThinkPad 365
ThinkPad 365C
ThinkPad 365CD
ThinkPad 365CS
ThinkPad 365CSD
ThinkPad 365E
ThinkPad 365ED
ThinkPad 365X
ThinkPad 380
ThinkPad 380D
ThinkPad 380D-MMX
ThinkPad 380E
ThinkPad 380ED
ThinkPad 380XD
ThinkPad 380Z
ThinkPad 385
ThinkPad 385CD
ThinkPad 390
ThinkPad 500

ThinkPad 535
ThinkPad 550
ThinkPad 560C
ThinkPad 560E
ThinkPad 560X
ThinkPad 560Z
ThinkPad 570E
ThinkPad 560
ThinkPad 570
ThinkPad 600
ThinkPad 600E
ThinkPad600X
ThinkPad 600A
ThinkPad 701C
ThinkPad 701CS
ThinkPad 770
ThinkPad 770E
ThinkPad 770ED
ThinkPad 770X
ThinkPad 770Z
ThinkPad A20
ThinkPad A20M
ThinkPad A20P
ThinkPad A21
ThinkPad A21E
ThinkPad A21M
ThinkPad A22
ThinkPad A22E
ThinkPad A22M
ThinkPad A30
ThinkPad A30P
ThinkPad A31
ThinkPad E530
ThinkPad i1800
ThinkPad R30
ThinkPad R31
ThinkPad R31E
ThinkPad R32
ThinkPad R32E
ThinkPad R33
ThinkPad R40
ThinkPad R40E
ThinkPad R50
ThinkPad R50E
ThinkPad R51
ThinkPad R51E
ThinkPad R52
ThinkPad R52E
ThinkPad S30
ThinkPad S31
ThinkPad T20
ThinkPad T21
ThinkPad T22
ThinkPad T23
ThinkPad T24
ThinkPad T30
ThinkPad T31
ThinkPad T40
ThinkPad T41
ThinkPad T42
IBM ThinkPad X20/X21/X22/X23/X24/X30/ X31/X32/X40/X41

ThinkPad :i1100, i1200, i1210, i1211, i1241, i1251 , i1271, i1300 , i1321, i1340 , i1351, i1361, i1391, i1418 , i1420, i1421, i1422, i1441 , i1442, i1460, i1480, i1482 i1483, i1492, i1500, i1540, i1541, i1542, i1560, d i1562 , i1592, i1700, i1720, i1721 , i1800

IBM Lenovo

T Series:T20，T21，T22，T23，T30，T40，T40P，T41，T41P，T42

X Series:X20，X21，X22，X23，X24，X30，X31，X40，x41，240X
R Series:R30，R31，R32，R40，R40E，R50，R50E，R50P，R51
i Series:i-1200，i-1210，i-1211，i-1241，i-1251，i-1271，i-1300，i-1321，i-1340，i-1351，i-1391，i-1418
A Series:A20，A20M，A20P，A21，A21E，A21M，A21P，A22E，A22M，A22P，A30，A30P，A31
240X，240Z，390，240X，340，345，360，370，380，365，365X，380，380D，380Z，385，550，560
560C，560E，560X，560Z，570，570E，600，600A，600E，600X，701，701C，770，770E，770Z

(19V)

Acer

Acer Aspire 1200	Acer Aspire 1610
Acer Aspire 1680	Acer Aspire 1620
Acer Aspire 1360	Acer Aspire 1660
Acer Aspire 1500	Acer Aspire 1670
Acer Aspire 1520	Acer Aspire 2010
Acer Aspire 1600	Acer Aspire 2020

Acer TravelmateTn 291LCI	Acer TravelMate 610TXV
Acer TravelmateTM 301XCI	Acer TravelMate 610TXC
Acer TravelmateTM 291LMI	Acer TravelMate 610
Acer TravelMate 8000	Acer TravelMate 604TER
Acer TravelMate 739TLV	Acer TravelMate 603TER
Acer TravelMate 738TLU	Acer TravelMate 603
Acer TravelMate 734TL	Acer TravelMate 602TER
Acer TravelMate 732TX	Acer TravelMate 602
Acer TravelMate 730TX	Acer TravelMate 600TER
Acer TravelMate 720	Acer TravelMate 6000
Acer TravelMate 660	Acer TravelMate 600
Acer TravelMate 613TXV	Acer TravelMate 551XV
Acer TravelMate 613TXC	Acer TravelMate 529TXV
Acer TravelMate 612TXV	Acer TravelMate 528TE
Acer TravelMate 612TXC	Acer TravelMate 525TXV
Acer TravelMate 611TXV	Acer TravelMate 525
Acer TravelMate 611TXC	Acer TravelMate 524TXV
Acer TravelMate 610TXVi	Acer TravelMate 522

Acer TravelMate 521TXV
Acer TravelMate 521TE
Acer TravelMate 521T
Acer TravelMate 520
Acer TravelMate 506DX
Acer TravelMate 506
Acer TravelMate 500
Acer TravelMate 4500
Acer TravelMate 4000
Acer TravelMate 354TEV
Acer TravelMate 354TE
Acer TravelMate 353TEV
Acer TravelMate 353TE
Acer TravelMate 352TE-n
Acer TravelMate 352TE
Acer TravelMate 351TE
Acer TravelMate 350TE
Acer TravelMate 347T
Acer TravelMate 345T
Acer TravelMate 342
Acer TravelMate 341T
Acer TravelMate 340T
Acer TravelMate 330T
Acer TravelMate 3200
Acer TravelMate 3000
Acer TravelMate 290E
Acer TravelMate 290
Acer TravelMate 270xv
Acer TravelMate 2700
Acer TravelMate 270
Acer TravelMate 2600
Acer TravelMate 260
Acer TravelMate 250PE

Acer TravelMate 2500
Acer TravelMate 250
Acer TravelMate 240
Acer TravelMate 2300
Acer TravelMate 225XV-Pro
Acer TravelMate 225XC
Acer TravelMate 225X
Acer TravelMate 223XC
Acer TravelMate 223X
Acer TravelMate 2203
Acer TravelMate 2200
Acer TravelMate 220
Acer TravelMate 213TXV
Acer TravelMate 213TX
Acer TravelMate 213T
Acer TravelMate 212TXV
Acer TravelMate 212TE
Acer TravelMate 212T
Acer TravelMate 210TER
Acer TravelMate 210T
Acer TravelMate 210
Acer TravelMate 2100
Acer TravelMate 2000
Acer TravelmateTM 252PE
Acer Travelmate C110
Acer TravelMate 735TLV
Acer TravelMate 600TER
Acer TravelMate 527TXV
Acer TravelMate 525TE
Acer TravelMate 330
Acer TravelMate 240
Acer TravelMate 2203LMI
Acer TravelMate 211T

Ferrari 3000
Ferrari 3000LMI
Acer Extensa 365
Acer Extensa 366D

Acer Extensa 367D
Acer Extensa 368D
Acer Extensa 390
Acer Extensa 390C

Acer Extensa 390CX
Acer Extensa 393
Acer Extensa 900
ACER Extensa ESS3-391T

Aspire 1710
Aspire AS2003LMi
AspireTM 240
AspireTM 250

Acer AcerNote 367D Series
Acer AcerNote 367T Series
Acer AcerNote 390 Series
Acer AcerNote 390A Series
Acer AcerNote 395 Series
Acer Anywhere1100LX Series
Acer Anywhere1120LX Series

Acer AcerNote 391 Series
Acer AcerNote 392 Series
Acer AcerNote 393 Series
Acer AcerNote 394 Series

Dell

Dell Inspiron 3000
Dell Inspiron 3200
Dell Inspiron 3500

ASUS

A1
A3
L1
L7
L8
M1
M2A
M5N
M8
S1
S2A/B
S3
S5N/Ne
S8
T9
Z2 series
Elite7200
Elite 73
Elite L7200

Elite L7200 B
Elite L8400
Elite L8400
Elite S8200
Elite S8600
F2F/Hf
A6V/R/U/F/Jc
F3F
A8F/H
A9
M9
M6
V6/VX1
W3V/A/Z
W5
W6F
Z35H/L
W7F
U5

S6	R1
Compaq	
298239-001	180675-001
177624-001	198714-001
177626-001	ADP-60BB
180676-001	API-7595
198713-001	ADP-9510-19A
208190-001	ADP-45TB
222113-001	CQPS1200
298237001	ADP-60DB
LE-9702A	API-7269
Delta	
A1	290E 291LCI 291LMI
L8	340T 341T 342
M5N	345T 347T 350
S2A/B/N S3	525TXV 528TE
T9	354TE 354TEV 360
L1	521TE 524TXV 525TE
M1	350TE 351TEV 352TE
M8	352TEN 353TE 353TEV
S5N/Ne	NX9005
Z2 series	DF988A
L7	DF989A
M2A	DF990A
S1	DF992A
S8	DF993A
5600 210 2101350 1360 1500	DF994A
1620 1670 1680	DG194A
210TER 211T 212T	DG195A
212TE 212TXV 213T	DG196A
3004WLM 3500 3610	DG200A
2003 3004LCI 3004LMI	DG201A
233XC 260 270	DG202A
270XV 280 290	DG203A
223X 223XC 225X	DG220T
301XCI 330 330T	DG221T
225XC 225XV 230	DG222T
213TX 213TXV 220	zd7012EA

Aspire 1710
Ferrari 3000
TM240 ZD7000
Ferrari 3000LMI
DR089U DR768E
DR340U DP764E
DM788A DM788A
DP769E DT859U
DM790A DP768E
DR761E DR762E
Aspire AS2003LMi
DP353E DN730AV
DP763E DM793AR
DM793A DP448UR
DP448U DR089UR
DP765E DM790AR
TM252PE TM291LCI
TM291LMI TM301XCI
A60-S156
A60-S1561
A60-S166
A60-S1661
A60-S1662
A65-S1063
A65-S1064
A65-S1065
A65-S1066
A60-S1591ST
DR770E DP761E
DP762E DP767E
DP770E DM791AR
DM791A DP766E
DP447U DP446U
DR769E 3005US
3008CL 3015CA
3015US 3017CL
3019CL 3020US
A65-S1067
A65-S1068
A65-S1069
A65-S1070
A65-S109
A75-2061
A75-S206
A75-S2091
A75-S211
A75-S2111
A75-S2112
A75-S226
A75-S2261
A75-S229

Gateway

Gateway Solo 2000
Gateway Solo 2150
Gateway Solo 2500
Gateway Solo 2500SE
Gateway Solo 2500LS
Gateway Solo 9150
Gateway Solo 1100
Gateway Solo 2100
Gateway Solo 2200
Gateway Solo 2300
Gateway Solo 9100
Gateway Solo 2550
Gateway Solo 5300
Gateway Solo 9300
Gateway Solo 9500
Gateway Solo 9550
Gateway Solo 9000 Series
Gateway Solo 5100
Gateway Solo 3000 Series
Gateway Solo 5000 Series
Gateway Solo 5150
Gateway Solo 1000 Series

Gateway Solo 2000 Series

Gateway NX500 Series
Gateway NX Series
Gateway ML3000 Series
Gateway Tablet PC
Gateway 3000 Series
Gateway 4000 Series
Gateway 6000 Series
Gateway CX Series
Gateway M Series
Gateway MT3000 Series

Gateway MX Series
Gateway NX200 Series
Gateway MT6800 Series
Gateway MT6700 Series
S-7200
S-7200C
CX200X Series
S7200 Series
CX200S
CX200

HP

298239-001
180676-001
177626-001
198713-001
222113-001
AC-C10
CQPS1200
261867-001
325112-001

325112-011
325112-061
325112-081
325112-111
325112-201
325112-291
325112-AA1
325112-AD1
325112-BB1

HP Omnibook Series
HP Omnibook Series XE2
HP Omnibook Series XE3
HP Omnibook Series 500
HP Omnibook Series 900
HP Omnibook Series 4100
HP Omnibook Series 4150
HP Omnibook Series 6000
HP Omnibook Series 7100
HP Omnibook Series 7150
HP Omnibook Series 2100
HP Omnibook Series 3000
HP Omnibook Series 3100
HP Pavilion Series N3150
HP Pavilion Series N3250
HP Pavilion Series N3270

HP Pavilion Series N3290/5
HP Pavilion Series N3310
HP Pavilion Series N3330
HP Pavilion Series N3390
HP Pavilion Series N3410
HP Pavilion Series N5000
HP Pavilion Series N5100
HP Pavilion Series N5125
HP Pavilion Series N5130
HP Pavilion Series N5150
HP Pavilion Series N5170
HP Pavilion Series N5190/5
HP Pavilion Series N5200

Pavilion :

ZV5000	ZV5000T	ZV5000Z
ZV5100	ZV5103	ZV5001US
ZV5001US	ZV5001US	ZV5002US
ZV5030CA	ZV5030CA	ZV5030US
ZV5030US	ZV5034US	ZV5034US
ZV5037WM	ZV5101US	PC898U
PC896U	ZV5105US	ZV5120CA
ZV5120US	PC897U	ZV5160CA
ZV5160US	ZV5200	ZV5201
ZV5220US		

IBM

ThinkPad i1400	ThinkPad i1442	ThinkPad i1460
ThinkPad i1480	ThinkPad i1482	ThinkPad i1500
ThinkPad i1522	ThinkPad i1700	ThinkPad i1720

Fujitsu

Fujitsu LifeBook A4170 Series	Fujitsu LifeBookA4187 Series
Fujitsu LifeBook A4177 Series	Fujitsu LifeBookA4190 Series
Fujitsu LifeBook A4178 Series	

Toshiba

DynaBook SS425Series

Satellite 1000	Satellite A100-155
Satellite Z2	Satellite A100-158
Satellite 1005	Satellite A100-159
Satellite 1005S101	Satellite A100-161
Satellite 1200	Satellite A100-165
Satellite S252	Satellite A100-166
Satellite 1600	Satellite A100-168
Satellite 1605CDS	Satellite A100-169
Satellite 1620CDS	Satellite A100-170
Satellite 1625CDT	Satellite A100-175
Satellite 1640CDT	Satellite A100-181
Satellite 1670CDS	Satellite A100-188
Satellite 1675CDS	Satellite A100-192
Satellite 1690CDT	Satellite A100-193

Satellite A100-209
Satellite A100-212
Satellite A100-218
Satellite A100-220
Satellite A100-232
Satellite A100-233
Satellite A100-270
Satellite A100-500
Satellite A100-507
Satellite A100-508
Satellite A100-510
Satellite A100-521
Satellite A100-522
Satellite A100-523
Satellite A100-525
Satellite A100-528
Satellite A100-529
Satellite A100-533
Satellite A100-534
Satellite A100-551
Satellite A100-JH2
Satellite A100-LE1
Satellite A100-LE4
Satellite 1695CDT
Satellite 1700
Satellite 1715XCDS
Satellite 1730
Satellite 1730CDT
Satellite 1735XCDS
Satellite 1755
Satellite 1755CDT
Satellite Series:

A100-163
A100-259
A100-295
A100-570
A100-649
A100-S2211
A110-101
A110-177
A110-178
A110-203

Satellite M40X-105
Satellite M40X-112
Satellite M40X-115
Satellite M40X-119
Satellite M40X-129
Satellite M40X-142
Satellite M40X-159
Satellite M40X-161
Satellite M40X-163
Satellite M40X-166
Satellite M40X-168
Satellite M40X-169
Satellite M40X-175
Satellite M40X-183
Satellite M40X-184
Satellite M40X-231
Satellite M40X-250
Satellite M40X-251
Satellite A100-237
Satellite A100-250
Satellite A100-269
Satellite A100-253

Satellite 1755CE
Satellite 1755DVD
Satellite 3000
Satellite 3000S
Satellite S353

A110-260
A110-289

A200-1BP
A200-10X
A200-10Z
A200-11C
A200-12F
A200-13L
A200-13O
A200-13R

A200-13T
A200-1AE

A105-S1014
A105-S101X
A105-S171
A105-S1712
A105-S171X
A105-S2001
A105-S2011
A105-S2021
A105-S2031
A105-S2051
A105-S2061
A105-S2071
A105-S2081
A105-S2091
A105-S2101
A105-S2111
A105-S2121
A105-S2131
A105-S2141
A105-S2194
A105-S2201
A105-S2204
A105-S2231

A110-339
A110-370
A200-13U
A200-14D
A200-14E
A200-180
A200-18T
A200-19I
A200-19K
A200-19M
A200-1A9
A200-1AA
A200-1AB
A200-1Ai

A105-S2236
A105-S271
A105-S2712
A105-S101
A105-S1012
A105-S1013

L35-S2151
L35-S2161
L35-S2171
L35-S2174
L35-S2194
L35-S1054
L35-S2316
A135-S2306
A135-S2326
A135-S2386
A135-S2396
A135-S4407
A135-S4417
A135-S4427
A135-S4437
A135-S4447

A135-S4457
A135-S2246
A135-S2256
A135-S2266
A135-S2276
A135-S2346
A135-S2356
A135-S2376
A135-S2286
A135-S2296

NEC

PA2409U
PA2411
PA2411U
PA2426U
PA2438
PA2438U
PA2440
PA2440U
PA2444
PA2444U
PA2444UE
PA3049U
PA3049U-1ACA
PA3080
PA3080E
PA3080E-1ACA
PA3080U
PA3080U-1ACA
PA3084 PA3084U
PA3084U-1ACA
PA3153
PA3153E
PA3153E-1ACA
PA3153E-1ACAB
PA3153U
PA3153U-1ACA
PA3201
PA3201U
PA3201U-1ACA
PA3241
PA3241E
PA3241E-1ACA
PA3241E-1ACAB
PA3241E-2ACA
PA3241U
PA3241U-1ACA
PA3241U-2ACA
PA3260E
PA3260E-1ACA
PA3260U
PA3260U-1ACA
PA3282
PA3282E
PA3282E-1ACA
PA3282E-2ACA
PA3282U
PA3282U-1ACA
PA3282U-2ACA
PA5251U
PA5251UA
PA3377E-2ACA

NEC Versa 2400

NEC Versa 2400CD

NEC Versa 2405
NEC Versa 2405CD
NEC Versa 2430
NEC Versa 2430CD
NEC Versa 2435C
NEC Versa 2435CD
NEC Versa 2500

DC Spec.	6.5 x 4.3 x 1.4mm	
Type	14.0/16.0/19.0/19.5V	
Notebook Brand	Fujitsu, Sony, Samsung	

(16V)

Fujitsu

Lifebook C Series

Lifebook C-4120
Lifebook C-4235
Lifebook C-5130
Lifebook C-5235
Lifebook C-6177
Lifebook C-6320
Lifebook C-6330
Lifebook C-6525
Lifebook C-6535
Lifebook C-6537
Lifebook C-6547
Lifebook C-6556
Lifebook C-6557
Lifebook C-6577
Lifebook C4023
Lifebook C25
Lifebook C5110
Lifebook C340
Lifebook C6140
Lifebook C6170

Fujitsu Lifebook E Series:

Lifebook E-5140
Lifebook E-5320
Lifebook E-5520
Lifebook E-6520
Lifebook E-6530
Lifebook E-6540
Lifebook E-6541
Lifebook E-6550
Lifebook E-6555
Lifebook E-6556
Lifebook E-6557
Lifebook E-6570
Lifebook E-6571
Lifebook E-6575
Lifebook E-6595
Lifebook E330
Lifebook E360
Lifebook E335
Lifebook E362
Lifebook E6596
Lifebook E340
Lifebook E342
Lifebook E350
Lifebook E6577

Fujitsu Lifebook I Series:

Lifebook I-4187
Lifebook I-4190

Lifebook I4120
Lifebook I4170
Lifebook I4177
Lifebook I4178
Lifebook 200 Series
Lifebook 400 Series
Lifebook 600 Series
Lifebook 700 Series
Lifebook B2130
Lifebook B2131
Lifebook B2175
Lifebook B2610
Stylistic LT P-600
Stylistic 1200
Stylistic 2300
Lifebook P2000
Lifebook S6010
Lifebook P2040
Lifebook P2110
Lifebook P2120
Lifebook S2000
Lifebook S4510
Lifebook S5582
Stylistic 3400
Stylistic 3500
Stylistic 500

SONY

PCG-505FXPCG-505GPCG-505GXPCG-505LS
PCG-505TRPCG-505TSPCG-505TXPCG-505X
PCG-591LPCG-505E
PCG-C1FPCG-C1MGPPCG-C1MHPPCG-C1MV
PCG-C1MVPPCG-C1XPCG-505EXPCG-505F
PCG-GR150KPCG-GR170KPCG-GR230PCG-GR250
PCG-GR250KPCG-GR250PPCG-GR270PCG-GR270K
PCG-GR270PPCG-GR290PCG-GR290KPCG-GR290P
PCG-GR300PCG-GR300KPCG-GR370PCG-GR370K
PCG-GR370PPCG-GR390PCG-GR390KPCG-GR390P
PCG-SR17PCG-SR17KPCG-SR27KPCG-SR33
PCG-SRX41PPCG-SRX77PCG-SRX77PPCG-SRX87
PCG-TR1APCG-TR1APPCG-TR1MPPCG-TR2A
PCG-V505 CTOPCG-V505 seriesPCG-V505APCG-V505A
PCG-V505ACPCG-V505AKPCG-V505APPCG-V505AC
PCG-V505AKPCG-V505APPCG-V505AXPCG-V505AXP
PCG-V505BPCG-V505BXPCG-V505BXPPCG-V505D
PCG-V505DC1PCG-V505DXPCG-V505DXPPCG-V505E
PCG-V505RPCG-V505 CTO

PCG-VX88PCG-VX88PPCG-VX89PCG-VX89K
PCG-VX89K1PCG-VX89PPCG-X505
PCG-Z1APCG-Z1A seriesPCG-Z1A1PCG-Z1AP1
PCG-Z1AP2PCG-Z1AP3PCG-Z1RAPCG-Z1RAP1
PCG-Z1RAP1KITBPCG-Z1RAP2PCG-Z1RAP3PCG-Z1VA
PCG-GR290PPCG-GR300PCG-GR300KPCG-GR370
PCG-GR370KPCG-GR370PPCG-GR390PCG-GR390K
PCG-SR5KPCG-SR7KPCG-SR9
PCG-SRX41PPCG-SRX77PCG-SRX77PPCG-SRX87
PCG-SRX87PPCG-SRX99PCG-SRX99KPCG-SRX99P

VAIO PCG-V505D	VAIO PCG-SRX77
VAIO PCG-SR17	VAIO PCG-C1X
PictureBook PCG-C1X	VAIO PCG-VX89K
VAIO PCG-GR390K	VAIO PCG-SRX77P
VAIO PCG-SR17K	VAIO PCG-GR
VAIO C1 PictureBook	VAIO PCG-VX89K1
VAIO PCG-V505DX	VAIO PCG-SRX87
VAIO PCG-SR27K	VAIO PCG-GR150K
VAIO PCG-505	VAIO PCG-VX89P
VAIO PCG-Z1VAP1	VAIO PCG-SRX87P
VAIO PCG-SR33	VAIO PCG-GR170K
VAIO PCG-591L	VAIO PCG-X505
VAIO PCG-V505EX	VAIO PCG-SRX99
VAIO PCG-SR5K	VAIO PCG-GR230
VAIO PCG-C1F	VAIO PCG-GR250
VAIO PCG-V505R	VAIO PCG-Z1A
VAIO PCG-SR7K	VAIO PCG-SRX99P
VAIO PCG-C1MGP	VAIO PCG-GR250K
VAIO PCG-V505BXP	VAIO PCG-GR390P
VAIO PCG-SR9	VAIO PCG-TR1AP
VAIO PCG-C1MHP	VAIO PCG-GR250P
VAIO PCG-VX88	VAIO PCG-Z1A1
VAIO PCG-SRX	VAIO PCG-TR1MP
VAIO PCG-C1MV	VAIO PCG-GR270
VAIO PCG-VX88P	VAIO PCG-Z1AP1
VAIO PCG-SRX41P	VAIO PCG-TR2A
VAIO PCG-C1MVP	VAIO PCG-Z1AP2
VAIO PCG-VX89	VAIO PCG-TR1A

VAIO PCG-GR270P
VAIO PCG-Z1AP3
VAIO PCG-V505 CTO
VAIO PCG-GR290
VAIO PCG-Z1RA
VAIO PCG-V505
VAIO PCG-SR
VAIO PCG-Z1RAP1
VAIO PCG-V505A
VAIO PCG-GR300K
VAIO PCG-Z1VAP2
VAIO PCG-V505AC
VAIO PCG-GR370
VAIO PCG-Z1RAP2
VAIO PCG-V505AK
VAIO PCG-GR370K

(19.5V)

SONY

VAIO PCG-731
VAIO PCG-735
VAIO PCG-808
VAIO PCG-729C
VAIO PCG-719C
VAIO PCG-717C
VAIO PCG-707C
VAIO PCG-705C
VAIO PCG-818
VAIO PCG-812
VAIO PCG-748
VAIO PCG-F150
VAIO PCG-F160
VAIO PCG-F180
VAIO PCG-F190
VAIO PCG-F270
VAIO PCG-F250
VAIO PCG-F280
VAIO PCG-F290
VAIO PCG-838
VAIO PICTUREBOOK
VAIO PCG-F350
VAIO PCG-F360
VAIO PCG-F370
VAIO PCG-F390
VAIO PCG-F340
VAIO PCG-XG9
VAIO PCG-Z505S
VAIO PCG-Z505SX
VAIO PCG-Z505R
VAIO PCG-Z505RX
VAIO PCG-F420
VAIO PCG-F430
VAIO PCG-F450
VAIO PCG-F480
VAIO PCG-F490
VAIO PCG-F480
VAIO PCG-F490K
VAIO PCG-XG18
VAIO PCG-XG1
VAIO PCG-Z505HE
VAIO PCG-Z505HS
VAIO PCG-Z505HSK
VAIO PCG-Z505JE
VAIO PCG-Z505JS
VAIO PCG-Z505JEK
VAIO PCG-Z505JSK
VAIO PCG-F520
VAIO PCG-F540
VAIO PCG-F560
PCG-505
PCG-505EX
PCG-505F
PCG-505FX

PCG-505G
PCG-505GX
PCG-505LS
PCG-505TR
PCG-505TS
PCG-505TX
PCG-505X
PCG-591L
PCG-C1F
PCG-C1MGP
PCG-C1MHP
PCG-C1MV
PCG-C1MVP
PCG-C1X
PCG-GR150K
PCG-GR170K
PCG-GR230
PCG-GR250
PCG-GR250K
PCG-GR250P
PCG-GR270
PCG-GR270K
PCG-GR270P
PCG-GR290
PCG-GR290K
PCG-GR290P
PCG-GR300
PCG-GR300K
PCG-GR370
PCG-GR370K
PCG-GR370P
PCG-GR390
PCG-GR390K
PCG-GR390P
PCG-SR17
PCG-SR17K
PCG-SR27K
PCG-SR33
PCG-SR5K
PCG-SR7K
PCG-SR9
PCG-SRX41P
PCG-SRX77
PCG-SRX77P
PCG-SRX87
PCG- SRX99
PCG-SRX99P
PCG-TR1A
PCG-TR1AP
PCG-TR1MP
PCG FR33
PCG FR33/B
PCG FR55/B
PCG FR55E
PCG FR55E/B
PCG FR77E/B
PCG 505
PCG R505D
PCG R505DL
PCG R505DS
PCG R505DSK
PCG R505DSP
PCG R505E
PCG R505EL
PCG R505EL/B
PCG 505E
PCG 505EX
PCG 505F
PCG 505FX
PCG 505G
PCG 505GX
PCG 505LS
PCG 505TR
PCG 505TS
PCG 505TX
PCG R505EL/S

PCG R505ELK
PCG R505ES
PCG R505ESP
PCG R505GC
PCG R505GL
PCG R505GLK
PCG CCN2
PCG R505ELKIT
PCG R505ESKIT
PCG R505ESPKIT
PCG R505GLPRO
PCG R505EC
PCG R505G
PCG 591L
PCG GRS50/B
PCG GRS55/B
PCG GRS52V/P
PCG GRS70/P
PCG GRS72
PCG GRS75
PCG GRS100
PCG GRS150
PCG GRS500
PCG GRS500P
PCG GRS600
PCG GRS700
PCG GRS900
PCG GRX51/BP
PCG GRX52/GB
PCG GRX71
PCG GRX72
PCG GRX81G/P
PCG GRX90/P
PCG GRX91G/P
PCG GRX92G/P
PCG GRX102/P
PCG GRX520
PCG GRX520/B
PCG GRX520K
PCG GRX520P
PCG GRX550
PCG GRX560
PCG GRX560/B
PCG GRX560K
VGN-A600
VGN-BX541B

VGN-S380
VGN-S380B
VGN-S460/B
VGN-S430P/S
VGN-S460P/B
VGN-S470P/S
VGN-S430P/S
VGN-S550P/S
VGN-S560P/B
VGN-S380
VGN-S380B
VGN-S570P/S
VGN-S470P/S
VGN-FS520B
VGN-FS660/W
VGN-FS530B
VGN-FS675P/H
VGN-FS540P
VGN-FS640/W
VGN-FS680/W
VGN-FS570
VGN-FS500P12
VGN-FS645P/H
VGN-FS742/W
VGN-FS625B/W
VGN-FS745P/H
VGN-FS630/W
VGN-FS775P/H

VGN-FS635B/W
VGN-FS780VGN
VGN-W500P12VGN
VGN-520BVGN
VGN-530B VGN-540P
VGN-635B/W
VGN-640/W
VGN-645P/H
VGN-660/W
VGN-675P/H
VGN-680/W
VGN-740/W
VGN-742/W
VGN-760/W
VAIO PCG-GRT100
VAIO PCG-GRT1002A
VAIO PCG-GRT160
VAIO PCG-GRT170
VAIO PCG-GRT230
VAIO PCG-GRT240G
VAIO PCG-GRT250
VAIO PCG-GRT260G
VAIO PCG-GRT2702
VAIO PCG-GRT270P21
VAIO PCG-GRT700
VAIO PCG-GRT715
VAIO PCG-GRT715E
VAIO PCG-GRT715M
VAIO PCG-GRT716
VAIO PCG-GRT716S
VAIO PCG-GRT796SP
VAIO PCG-GRT796
VAIO PCG-FRV25
VAIO PCG-FRV26
VAIO PCG-FRV27
VAIO PCG-FRV28
VAIO PCG-FRV31
VAIO PCG-FRV37
VAIO PCG-GRV616S
VAIO PCG-GRV616G
VAIO PCG-GRV550
VAIO PCG-GRV600
VAIO PCG-GRV670
VAIO PCG-GRV670P
VAIO PCG-GRV680
VAIO PCG-GRV680P
VAIO PCG-GRZ10
VAIO PCG-GRZ20
VAIO PCG-GRZ230
VAIO PCG-GRZ270
VAIO PCG-GRZ515
VAIO PCG-GRZ515G
VAIO PCG-GRZ530
VAIO PCG-GRZ600P1
VAIO PCG-GRZ600P3
VAIO PCG-GRZ600P6
VAIO PCG-GRZ610
VAIO PCG-GRZ615M
VAIO PCG-GRZ600
VAIO PCG-GRZ615G
VAIO PCG-GRZ615S
VAIO PCG-GRZ630
VAIO PCG-GRZ660
VAIO VGN-A130
VAIO VGN-A150
VAIO VGN-A160
VAIO VGN-A190
VAIO VGN-A260
VAIO PCG FRV25
VAIO PCG FRV26
VAIO PCG FRV27
VAIO PCG FRV28
VAIO PCG FRV37
VAIO PCG GRT70
VAIO PCG GRT160
VAIO PCG GRT230

VAIO PCG GRT270
VAIO PCG GRT240G
VAIO PCG GRT260G
VAIO PCG GRT270G
VAIO PCG GR VAIO PCG GRT280ZG
VAIO PCG GRT1002A
VAIO PCG GRT250PL
VAIO PCG GRT290ZP27
VAIO PCG GRT2702P21 T100

DC Spec.	4.8 x 1.7mm	
Type	18.5V/19.0V	
Notebook Brand	ASUS, HP	

(18.5V)

Compaq

Compaq Armada 110
Compaq Armada 100
Compaq Armada 100S
Compaq Armada 150
Compaq Armada E500
Compaq Armada V300
Compaq Armada E300
Compaq Armada M700
Compaq Armada E500S
Compaq Armada E700
Compaq Armada M300
Compaq Armada 1500
Compaq Armada M700
Compaq Armada N110
Compaq Armada N150
Compaq Armada N200
Compaq Armada N400C
Compaq Armada N600C
Compaq Armada N800C
Compaq Armada N800V
Compaq Armada N410C
Compaq Armada 1640
Compaq Armada 305

Compaq Evo N1000
Compaq Evo N1000C
Compaq Evo N1000V
Compaq Evo N1010V
Compaq Evo N1015V
Compaq Evo N1020V
Compaq Evo N1050V
Compaq Evo N400
Compaq Evo N600
Compaq Evo N600C
Compaq Evo N610C
Compaq Evo N620C
Compaq Evo N110
Compaq Evo N200
Compaq Evo N400C
Compaq Evo N410
Compaq Evo N800
Compaq Evo N800C
Compaq Evo N800V
Compaq Evo N800W
Compaq Evo N150
Compaq Evo N100

V2110CA,V2130
V2305,V2305CA,V2305US

V2552,V2552US,V2555
V2135,V2135US,V2140
V2306,V2306US,V2309
V2555US,V2555CA,V2565
V2140US,V2140CA,
V2309US,V2310
V2565US, V2565CA
V2146,V2146CL
V2400,V2400CTO,V2401
V2600,V2610,V2610US
V2200,V2205,V2205US
N1000C,EVO Notebook
N110,N150,N200,N400
N600c,N610c, N1000V
V2640,V2640NR,V2665
V4000,V4000z,V4001
V2665US,V2698,V2699
V4020US,V4025
Compaq Prosignia 140
Compaq Prosignia 150
Compaq Prosignia 160
Compaq Prosignia 165
Compaq Prosignia 190
Compaq Presario 1510US
Compaq Prosignia 170SMB
Compaq Prosignia 190SMB
Compaq Presario 1500
Compaq Presario 1500T
Compaq Presario 1500US
Compaq Presario 1501CL
Compaq Presario 1505US
Compaq Presario 1525US
Compaq Presario 900

V2401CL,V2402,V2402US
V2208,V2208C,V2210,
V2403,V2403NR,V2403US
V2210US,V2210CA,
V2404,V2404US,V2405
V2220,V2220US
X1200,X1201,X1201US
X1230,X1230US
X1210,X1210CA
X1210USX1220,X1220US
X1360CA,X1370,1370US
X1360,X1360US,X1360CL
X1390,X1390US,X1937
X1300,X1301,X1301US
EVO N1000C,EVO N1000V
EVO N1005V,EVO Notebook
V4002,V4003,V4004
V4005,V4005CL,V4015
Compaq Presario 905
Compaq Presario 905US
Compaq Presario 906US
Compaq Presario 910
Compaq Presario 910US
Compaq Presario 912
Compaq Presario 912rsh
Compaq Presario 918
Compaq Presario 918rsh
Compaq Presario 920
Compaq Presario 1516US
Compaq Presario 920US

E-Machines M5000
E-Machines M5105
E-Machines M5305

E-Machines M5309
E-Machines M5310
E-Machines M5312

E-Machines M5313
E-Machines M6811
E-Machines M5405
E-Machines M5410
E-Machines M6805
E-Machines M6807
E-Machines M6809

Presario V1000 Series: V1000, V1100, V1300
Presario V2000 Series: V2000, V2100, V2200, V2300, V2400, V2500, V2600, V2700
Presario V3000 Series: V3000, V3100
Presario V4000 Series: V4000, V4100,V4200, V4300, V4400
Presario V5000 Series: V5000, V5100, V5200, V5300
Presario V6000 Series: V6000AU, V6000Z, V6001AU, V6001XX, V6002AU, V6002XX, V6003AU, V6004AU, V6012EA, V6014EA, V6016EA, V6024EA, V6025EA, V6030US, V6048CL, V6057EA, V6065EA, V6066EA
Presario X Series: X1000, X1100, X1200, X1300, X1400, X1500

HP:

Notebook PC : 500,510,520,530,550, 6720s

Business Notebook NC Series: NC4000, NC4010, NC4200,NC6000, NC8000

Business Notebook NX Series: NX4300, NX4800, NX5000,NX5100, NX6110, NX6125, NX6130, NX7000, NX9000

Business Notebook NW Series: NW8000

Tablet PC: Tablet PC TC1100, TC1000, TC4200 .

Pavilion DV1000 Series: DV1000,DV1100,DV1200,DV1300,DV1400, DV1500, DV1600, DV1700

Pavilion DV2 Series

Pavilion DV4000 Series: DV4000,DV4100,DV4200,DV4300,DV4400

Pavilion DV5000 Series: DV5000, DV5100, DV5200, DV5300

Pavilion DV6000 Series

Pavilion DV8000 Series: DV8400

Pavilion DX Series: DX6600, DX6700

Pavilion TX Series: TX1000, TX1100, TX1200, TX1300, TX1400,

TX2000, TX2100, TX2500, TX2506, SmartTouch TX2-1003AU

Pavilion ZE Series: ZE2000, ZE2100, ZE2200, ZE2300, ZE2400,

ZE2500, ZE4900

Pavilion ZT Series: ZT3000, ZT3100, ZT3200, ZT3300, ZT3400

HP Compaq:

HP Compaq NC Series: NC4000, NC4010, NC4200, NC5000, NC60 00, NC6100, NC6110, NC6120, NC6140,NC6200,NC6220,NC8000, NC8230

HP Compaq NX Series: NX4800,NX4820,NX5000,NX6100,NX6105, NX6110, NX6115, NX6120, NX6125, NX6130, NX6330, NX7000, NX7010, NX7100, NX7200, NX7220, NX9020, NX9030, NX9040

HP Compaq NW Series: NW8000, NW8440

DC Spec.	5.5 x 2.1mm	
Type	19.0V	
Notebook Brand	Acer	

(19V)

Acer

Acer AcerNote 330T,Acer Aspire 1200
Acer TravelMate
210/210T/210TER/212T/212TE/212TXV/213T/213TXV
Acer TravelMate 220/223X/223XC/225X/225XC/225XV-Pro
Acer TravelMate 230/233XC/240/260/270/270xv/280/290
Acer TravelMate 330/330T/340T/350/351TEV/360
Acer TravelMate 500/506/506DX
Acer TravelMate

520/521T/521TE/521TXV/522/525/525TXV/527TXV/529TXV/530
Acer TravelMate 600/600TER/602/602TER/603/610/620/630
Acer TravelMate
730/730TXV/732/732TLV/735TLV/735TXV/738TLV/739TLV/740
Acer TravelMate a550/a551,Acer TravelMate Alpha 550/551

DC Spec.	5.5 x 1.7mm	
Type	19.0V	
Notebook Brand	Acer	

(19V)

Acer Aspire 1200, Acer Aspire 1650, Aspire 2920 Series, Acer Aspire 3030, Acer Aspire 3200, Acer Aspire 3510, Acer Aspire 3670, Acer Aspire 4310, Acer Aspire 4315, Acer Aspire 4320, Acer Aspire 4520, Acer Aspire 4715Z, Acer Aspire 5220, Acer Aspire 5310, Acer Aspire 5315, Acer Aspire 5510

Acer Extensa EX4220, Acer Extensa EX4620, Acer Extensa EX4620Z, Acer Extensa EX5010, Acer Extensa EX5120, Acer Extensa EX5210, Acer Extensa EX5220, Acer Extensa EX5410, Acer Extensa EX5420, Acer Extensa EX5420G, Acer Extensa EX5610, Acer Extensa EX5610G, Acer Extensa EX5620, Acer Extensa EX5620G

Acer Ferrari 1000 Series, Acer Ferrari 1100 Series, Ferrari 11005457, Ferrari 1100552G16Mn, Ferrari 1100702G25Mn, Ferrari 1100704G25Mi, Ferrari 1100704G25Mn, Acer Ferrari 1004WTMi, Acer Ferrari FR1004WTMi

Acer TravelMate 2460, Acer TravelMate 2470, Acer TravelMate 3020, Acer TravelMate 3030, Acer TravelMate 3040, Acer TravelMate 3220, Acer TravelMate 3230, Acer TravelMate 3300, Acer TravelMate 360, Acer TravelMate 380, Acer TravelMate 4050, Acer TravelMate 4080, Acer TravelMate 4320, Acer TravelMate 4520, Acer TravelMate 4600, Acer TravelMate 4720, Acer TravelMate 530, Acer TravelMate 5310, Acer TravelMate 5320, Acer TravelMate 6231, Acer TravelMate 6291, Acer TravelMate 6292, Acer TravelMate 7220, Acer TravelMate 7364, Acer TravelMate 7520, Acer TravelMate A550

DC Spec.	4.0 x 1.7mm	
Type	19.0V	
Notebook Brand	Sony	

(19V)

DC Spec.	3.5 x 1.35mm	
Type	22.0V	
Notebook Brand	Sharp	

(22V)

Suit for SHARP 22V 2.04A models